

SINGLE STAGE WOOD DUST COLLECTOR



APZEM Wall Hanging Dust Collector to your wall and keep precious floor space free of clutter. This Dust Collector will handle just about any dust producing machine in your shop in a point-of-use, dedicated setup. A simple mounting bracket allows you to hang this dust collector on the wall, or mount it to a bench or the floor. which is designed to capture dust and wood chips from one woodworking machine at a time, such as a table saw, jointer, or planer. The air drawn in by the dust collector is filtered through a cloth collection bag that can be removed and emptied when full.

FEATURES

- Industrial-quality construction effectively handles collection of wood chips and sawdust
- Quick-install collection bag makes emptying and re-attaching a snap
- Single-stage design for economical and quiet operation
- High air velocity (CFM) design stands up to any competitive specifications

ACCESSORIES



DUCT



BAG FILTER



WIRE HOSE CLAMP



MODEL NO	DESCRIPTION
SD110	3/4 HP, Apzem Wall Mount Dust Collector
SD120	1 HP, Apzem Wall Mount Dust Collector

SINGLE STAGE WOOD DUST COLLECTOR

APZEM Portable single stage wood dust collector is designed to capture dust and wood chips from one woodworking machine at a time, such as a table saw, jointer, or planer. The air drawn in by the dust collector is filtered through a cloth collection bag that can be removed.



FEATURES

- Spark resistant, self-cleaning, cast aluminum, radial wheels are standard
- Totally Enclosed motors are standard
- Motors are continuous duty, full horsepower rated
- Drums are not included and plastic drums should never be used for any models
- Safe, no exposed moving parts
- Easy operational
- High efficiency
- Low noise levels
- Small footprint

ACCESSORIES



DUCT



BAG FILTER



WIRE HOSE CLAMP



CASTER WHEEL



FRONT VIEW

BACK VIEW

MODEL NO	DESCRIPTION
SD210	3/4 HP, Apzem Portable Dust Collector
SD220	1 HP, Apzem Portable Dust Collector

SINGLE STAGE WOOD DUST COLLECTOR

APZEM dust collectors hook up to 1 to 3 machines at a time for optimum dust cleaning. Apzem dust collector comes equipped with a quick-install collection bag, single-stage design for economical and quiet operation, 4 casters for maneuverability and total portability, and permanently lubricated, fully enclosed, fan-cooled motors for continuous duty.



FEATURES

- Hook up one to three machines for optimum dust cleaning
- Quick-install collection bag makes emptying and re-attaching a snap
- Single-stage design for economical and quiet operation
- Includes four casters for maneuverability and total portability
- Permanently lubricated, totally enclosed, fan-cooled motors are rated for continuous-duty



FRONT VIEW



RIGHT SIDE VIEW

ACCESSORIES



BAG CLAMP



BAG FILTER



DUST COLLECTION ACCESSORIES KIT



DUCT

MODEL NO	DESCRIPTION
SD250	1 HP, Portable, double inlet, with single bag, Single stage dust collector - 30 micron bag (5 micron optional)

SINGLE STAGE WOOD DUST COLLECTOR

APZEM wood dustcollector improves chip separation to prevent clogging of the filter, and increases packing efficiency of the collector bag. The high air velocity (CFM) stands up to any competitive specifications, and the industrial controls are designed for years of durable use. Collection bags have an elastic band for fast installation and removal.

FEATURES

- Quick-install collection bag makes emptying and re-attaching a snap
- Single-stage design for economical and quiet operation
- Includes four casters for maneuverability and total portability
- High air velocity (CFM) design stands up to any competitive specifications
- Permanently lubricated, totally enclosed, fan-cooled motors are rated for continuous-duty



FRONT VIEW



RIGHT SIDE VIEW

ACCESSORIES



BAG CLAMP



BAG FILTER



DUST COLLECTION ACCESSORIES KIT



DUCT

MODEL NO	DESCRIPTION
SD310	1.5 HP, Portable, double inlet, with single bag, Single stage dust collector - 30 micron bag (5 micron optional)
SD320	2 HP, Portable, double inlet, with single bag, Single stage dust collector - 30 micron bag (5 micron optional)

SINGLE STAGE WOOD DUST COLLECTOR

APZEM Wood dustcollector is designed to capture dust and wood chips from wood working machines, such as table saws, jointers, and planers. The air drawn in by the dust collector is filtered before it returns to the workspace.



FEATURES

- Industrial-quality construction effectively handles collection of wood chips and sawdust
- Quick-install collection bag makes emptying and re-attaching a snap
- Single-stage design for economical and quiet operation
- Includes four casters for maneuverability and total portability
- High air velocity (CFM) design stands up to any competitive specifications
- Permanently lubricated, totally enclosed, fan-cooled motors are rated for continuous-duty



FRONT VIEW



RIGHT SIDE VIEW

ACCESSORIES



BAG CLAMP



DUCT



PLASTIC BOTTOM



CARTRIDGE FILTER

MODEL NO	DESCRIPTION
SD410	1.5 HP, Portable, double inlet, with single canister, Single stage dust collector - 2 micron
SD420	2 HP, Portable, double inlet, with single canister, Single stage dust collector - 2 micron

SINGLE STAGE WOOD DUST COLLECTOR

APZEM Dust Collector is strong enough to use with planers, wide belt sanders, table saws and most other woodworking machines. The exclusive APZEM improves chip separation to prevent clogging of the filter, and increases packing efficiency of the collector bags. The canister filter offers superior filtering surface area over standard bags, and captures 98% of 2-micron particles.



FEATURES

- All-metal duct construction for rigidity and improved air flow
- 30-micron filter bags for improved capture of fine dust particles
- The large impeller is powered by a 3HP motor for peak performance
- Triple 4" dust ports allow for several hoses to be attached at the same time
- Cloth collection bags with view window use a snap ring for rapid installation/removal
- 10 cubic feet collection bag capacity reduces number of bag changes
- Tall filter bags require less cleaning due to the larger surface area
- Four swivel casters for easy maneuverability

ACCESSORIES



PLASTIC BOTTOM



DUCT



BAG CLAMP



BAG FILTER



FRONT VIEW



RIGHT SIDE VIEW

MODEL NO	DESCRIPTION
SD510	3 HP, Portable, triple inlet, with double bag, Single stage dust collector - 30 micron bag (5 micron optional)
SD520	5 HP, Portable, triple inlet, with double bag, Single stage dust collector - 30 micron bag (5 micron optional)

SINGLE STAGE WOOD DUST COLLECTOR



APZEM Dust Collector is strong enough to use with planers, wide belt sanders, table saws and most other woodworking machines. The exclusive APZEMimproves chip separation to prevent clogging of the filter, and increases packing efficiency of the collector bags. The canister filter offers superior filtering surface area over standard bags, and captures 98% of 2-micron particles.

FEATURES

- All-metal duct construction for rigidity and improved air flow
- 30-micron filter bags for improved capture of fine dust particles
- The large impeller is powered by a 3HP motor for peak performance
- Triple 4" dust ports allow for several hoses to be attached at the same time
- Cloth collection bags with view window use a snap ring for rapid installation/removal
- 10 cubic feet collection bag capacity reduces number of bag changes.
- Tall filter bags require less cleaning due to the larger surface area
- Four swivel casters for easy maneuverability

ACCESSORIES



PLASTIC BOTTOM



BAG CLAMP



DUCT



FRONT VIEW



RIGHT SIDE VIEW

MODEL NO	DESCRIPTION
SD610	3 HP, Portable, Triple inlet, with double canister, Single stage dust collector.
SD620	5 HP, Portable, Triple inlet, with double canister, Single stage dust collector.